




HOW TO CHANGE PICTURE DISCS

Some phenakistoscope handles are held horizontal such as the one you have.



Unscrew the nut from the bolt on the end of handle.



Place disc onto shaft of the bolt and replace nut.

Spin, view, enjoy!

