

SPECIAL INSTRUCTIONS

The pictures in this reel are made on full color KODACHROME film and reasonable care should be exercised in handling.

Do not touch pictures with fingers; do not store in hot or damp place. Clean with soft cloth or camel's hair brush. Keep reel in carton when not in use.

Made by
SAWYER'S
Portland 7, Oregon
U.S.A.

INSTRUCTIONS FOR OPERATING

Sawyer's
VIEW-MASTER






FIG. 1

Your Viewmaster comes to you adjusted and tested for proper operation; just pull lever A, Fig. 2, as far as it will go, and release. Repeat this operation when ready to change views.

To change reels, raise the catch B, Fig. 2, and take out reel by inserting finger through title window C, Fig. 3. Place new reel D, Fig. 1, with title side toward title window and close viewer. Pull lever A, Fig. 2, once or twice before viewing.

See page 4 for instructions on care of reels.



FIG. 3



FIG. 2