

REMOVE BEFORE USING

Operating Instructions for De Luxe View-Master Stereoscope

- No. 1. Insert Reel in this slot with titles towards lenses and push in firmly.
- No. 2. Pull picture changing lever down as far as it will go to bring picture into proper registration.

TO CHANGE REELS. Pull out old Reel and insert new Reel as described above.

TO CLEAN LENSES: Wipe gently with a circular motion, using a dry soft cloth.

To Enjoy Your VIEW-MASTER More

. build a complete library of
View-Master Reels!

SELECT FROM

NATIONAL PARKS
WILD FLOWERS
BIBLE STORIES
SWITZERLAND

FAIRY STORIES
ENGLAND
LATIN AMERICAN
SCENIC

. and many other fascinating subjects.

PROJECT YOUR VIEW-MASTER PICTURES.

The new View-Master two-dimensional Projector is designed to use View-Master Picture Reels. Ideal for home, classroom and commercial use. Simple operation.

Sturdy construction. Ask your photographic dealer.

