

# "IVIK" 16m.m. MOVIESCOPE

## INSTRUCTIONS

### To Operate:

Fit loop holder in to side of Moviescope with metal loop outside.

### How to insert loop into Moviescope:

Hold open the brass film door—place loop into the film channel and let door close. Gently ease film up or down until claw has clicked into a film hole, pass film through metal loop holder.

Place Moviescope on to sheet of white paper and direct daylight or artificial light on to white paper underneath the gate.

Turn handle **Clockwise**.


To clean lenses use only soft brush or clean, soft fabric.

**DO NOT** turn handle backwards, or pull film upwards.

” ” open forward box.


” ” bend or alter tension of film door.

**ALL** "Filmettes" are non-inflammable.




## How to Make or Repair a Loop from Your "Filmette"


First cut off arrow and serial number at end of film. (If any)



1.—Take the two ends of the 'Filmette' and overlap the first two pictures or 'frames' with the last two pictures, so that the film holes lie **EXACTLY** on top of each other.



2.—Holding the overlapping ends firmly cut with scissors through the double thickness of film. Make sure you cut **only** through the centre of a picture as illustrated.



3.—When now examined you will see that the two ends of the film match up exactly. Now form your film loop by lining up the two cut ends together but **NOT** overlapping.

Seal with a small piece of Sellotape on both sides—making sure that the film holes are **NOT** covered with the Sellotape. Your loop is now ready for use.

**IMPORTANT NOTICE:** All 'Filmettes' are specially treated for protection and long life by a chemical wax solution. If you find the film slips in the gate, rub the film between finger and thumb, this will remove any excess wax.