



STAR WARS® SLIDE VIEWER




1. Assemble decorative button.

2. Loosen screw. Remove battery compartment door.




3. Follow the engraved diagram for proper installation of the two (AA) alkaline batteries.

After the batteries are installed, replace compartment door and tighten screw.




CAUTION: To avoid battery leakage, 1. Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions. 2. Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable batteries. 3. Always remove exhausted or dead batteries from the product.



4. Insert a slide into the viewer. Press down on the slide to light the bulb. Look through the lens to see the slide.

Straps have self-gripping fasteners so they can be put together.

5. To replace the light bulb, first remove the batteries. Then remove 2 screws and lift out bulb holder. Replace bulb, put batteries back in place.



Kenner®

*®, & © 1998 HASBRO, INC.
Pawtucket, Rhode Island 02862.
All Rights Reserved
®, TM & © 1998 Lucasfilm Ltd.
All rights reserved.
Used under authorization.
C - 060A